


## Procedure to be followed in setting up your Tick-Off Machine

	STEP 1	Make a hole slightly (17 cm) deeper than the height of the applicator and about 25cm longer on each side. Provide a fairly level base for the unit.
	STAP 1	Maak 'n gat effe dieper (17cm) as die hoogte van die toestel sowat 25cm langer aan beide kante. Die bodem van die gat moet redelik gelyk wees.
	STEP 2	Fit spry pipe to Tick Off unit with two nineteen millimeter keys. (Long spry pipe on filler pipe side.)
	STAP 2	Maak spuit punte teen Tick Off toestel vas met behulp van twee negentien millimeter sleutels. (Lang pyp aan filler se kant.)
	STEP 3	Place the unit in the hole moving it around to make sure it is bedded well.
	STAP 3	Plaas die toestel in die gat en skuif dit rond totdat dit stewig en gelyk is.
	STEP 4	Mount extended spry pipe to a tree (pole) 1.8 meter high and half meter from system, be sure the nozzle is angled toward the nozzle between the rocks.
	STAP 4	Monteer lang uitlaat teen boom (paal) 1.8 meter hoog en half meter weg van toestel, maak seker dat spuitpunt na onderste spuitpunt gerig is.
	STEP 5	Place a rock on each side of the outlets for protection, filler pipe and breather pipe must stick out of ground.
	STAP 5	Plaas 'n groot klip aan beide kante van die uitlate vir beskerming, filler pyp en lug pyp moet by grond uitsteek.



STEP 6

Cover the unit with a 50mm layer of soil, level with the surrounding area. Protect the short nozzle between rocks, angled upward and inward.

STAP 6

Bedek die toestel met 'n +/- 50mm laag grond sodat die kante gelyk is met die wal van die gat. Beskerm die spuitpunt tussen die twee klippe, buig op en binne toe.



STEP 7

Fill the unit with +/- 5 liters of insecticide (unit can hold 20 Liters). Be careful not to get sand and dirt into the unit although there are built-in filters.

STAP 7

Vul die toestel met +/- 5 liter opgietsmiddel (toestel kan 20 Liter hou) Voorkom dat sand en stof nie die toestel binne dring nie, al is daar ingeboude filters.



STEP 8

Unscrew both nozzles and step on unit to get all the air out of pipe`s.

STAP 8

Skroef al twee spuitpunte af en trap op die toestel om die lug uit die pype te kry.



STEP 9

Fit nozzles. Make sure it squirts an uninterrupted stream. If not, press a few times to get any air out of the pipe`s. If it runs empty after a while, simply refill and repeat step 8.

STAP 9

Maak seker dat toestel 'n egalige straal spuit. Pomp 'n paar keer om lug uit pype te kry. Indien dit leeg loop hervul stelsel en herhaal stap 8.



STEP 10

Place large thornbush halfway over the unit and cut back so that strong branches form sides of the pathway. 1 meter high and 30 meters to a side, in a straight line.

STAP 10

Plaas takke aan beide kante van toestel +/- 1m hoog en 30m na beide kante. Sny terug sodat sterker takke 'n stewige kant van die poort vorm.



STEP 11

Check that the system's set correctly. Be sure to check that the long outlet squirts the insecticide right across to the short outlet.

STAP 11

Sorg dat die kort spuit na die boonste spuit toe spuit, en teenoorgestel. (na mekaar toe).